

MTS Extra Length Drills

For extra deep hole drilling.

Forets extra-longs MTS

Pour le perçage de trous très profonds.

MTS-Bohrer, überlang


Für das Bohren von besonders tiefen Bohrungen.

Brocas MTS extra largas

Para taladrar a una mayor profundidad.

Сверла с коническим хвостовиком
Морзе экстра длинной серии

Сверла общего назначения для сверления особо глубоких отверстий.


Codes
242
244 - 245
Properties

mm **WORKS STD.** **HSS**

Cutting Data

pg 61



P								M				K				Ti			Ni			Cu				N				Syn		
1.1	1.2	1.3	1.4	1.5	1.6	1.7	1.8	2.1	2.2	2.3	2.4	3.1	3.2	3.3	3.4	4.1	4.2	4.3	5.1	5.2	5.3	6.1	6.2	6.3	6.4	7.1	7.2	7.3	7.4	8.1	8.2	8.3
●	●	●	●	○	○							●	●	○	○							○	○	○	○	○	○	○	○			

d	MTS	l ₂	l ₁	200		300		300		375		375	
				315	400	450	500	530					
10	1			2421000									
10.5	1			2421050									
11	1			2421100		2441100							
11.5	1			2421150									
12	1			2421200		2441200							
13	1			2421300		2441300							
14	1			2421400		2441400							
15	2			2421500		2441500							
16	2			2421600		2441600				2451600			
17	2			2421700		2441700				2451700			
18	2			2421800		2441800				2451800			
19	2			2421900		2441900				2451900			
20	2			2422000		2442000				2452000			
21	2			2422100		2442100				2452100			
22	2			2422200		2442200				2452200			
23	2			2422300		2442300				2452300			
24	3								2442400	2452400			
25	3								2442500	2452500			
26	3								2442600	2452600			
27	3								2442700	2452700			
28	3								2442800	2452800			
29	3								2442900	2452900			
30	3								2443000	2453000			
32	4								2443200		2453200		
35	4								2443500		2453500		
38	4								2443800		2453800		
40	4								2444000		2454000		
42	4								2444200		2454200		
45	4								2444500		2454500		
48	4								2444800		2454800		
50	4								2445000		2455000		

